

Sonos® Controller

Instantly access your entire music collection, plus Internet radio, from anywhere.



The Sonos Controller gives you complete control over all your music and all your ZonePlayers from the palm of your hand.

With the Sonos Controller and SonosNet™, our secure wireless mesh network, you can instantly access all your digital music, plus subscriptions to online music and radio services, Internet radio and even music from your favorite CD or MP3 player—from anywhere. Turn off the upstairs music while you're downstairs. Change the song in the kitchen from the bedroom. It's all in your hands.

Unlike other remote controls, the Sonos Controller features a 8.89 cm full-colour LCD screen and scroll wheel so you can see album art, browse playlists, get detailed track information, and more. To get started, just pick a room, pick a song and hit play. You can use up to 32 Controllers for all your ZonePlayers—one for every room, floor or music lover in your house.



www.sonos.com

SONOS®



Sonos Controller (CR100)

Wirelessly control all your music and all your ZonePlayers from the palm of your hand.

Wireless, handheld control	Control everything from volume to music selection from anywhere you choose. SonosNet, our secure AES encrypted wireless mesh network, extends the range of the Controller and avoids sources of wireless interference by communicating with the closest ZonePlayer, rather than through one distant control point.
High-resolution, full-colour LCD screen	Makes everything on the screen brighter and easier to see, including full-colour album artwork, if available. Screen is optimized for indoor and outdoor use.
Album art	Displays full-screen and thumbnail views of full-colour album art, including detailed track information.
Scroll wheel selector	Makes it quick and easy to scroll through large music collections and make selections.

TECHNICAL SPECIFICATIONS*

Screen	8.89 cm (diagonal) colour LCD with LED backlighting, 240 x 320 (QVGA)
Scroll wheel	Touch-sensitive scroll wheel with centre-mounted selector button
Function buttons	9 backlit buttons, 3 soft-selector buttons below screen
Battery	Rechargeable Li-ION Polymer, factory-replaceable
Wireless connectivity	SonosNet, a secure AES encrypted, peer-to-peer wireless mesh network
DC charger	Input 100-240 VAC, 50-60 Hz; Output 6 VDC, 3.8A
Dimensions/Weight	165 x 97 x 24.5 mm (6.5 x 3.8 x 0.95 in)/360 g (12.5 oz)



Sonos® Charging Cradle (CC100)

Designed to hold and charge your Sonos Controller.
(Sold separately.)

Designed for use with the Controller's existing AC Adapter. *The Charging Cradle does not come with an AC Adapter.*

Controller is fully functional while in the cradle. Controller LEDs indicate the charge status.

Place on any desktop or mount on any wall using the anchors, brackets and screws provided.

TECHNICAL SPECIFICATIONS*

Colour/Material	Light grey matched to the Controller/High-quality PC-grade plastic; blue rubber padding on bottom to provide firm grip
Dimensions/Weight	65 x 57 x 189 mm (2.6 x 2.2 x 7.4 in)/200 g (7.1 oz)

*Specifications are subject to change without notice.

www.sonos.com